

OXYGEN

by
guzzie+guss®

Imported in North America by :
Peter John M. Distributions inc.
#114 - 6951 - 72nd street
Delta, BC, Canada V4G 0A2

info@guzzieandguss.com
1-888-597-0992

Please read this instruction manual carefully before using this product.
Be sure to save these instructions for future reference.

WARNINGS Please note the following to ensure safe use of your stroller

- Never leave child in the stroller unattended.
 - Care must be taken when folding and unfolding the product to prevent finger entrapment.
 - To avoid entrapment or pinching, do not fold or unfold stroller when child is in or within reach of the stroller.
 - To avoid serious injury from falling or sliding out, always use harness to secure your child.
 - Child may slip into leg openings and strangle. Never use in reclined carriage position(s) unless using the safety harness and the footrest enclosure.
 - When using the stroller seat from birth to 4 months, always use the footrest enclosure or an infant car seat that is properly attached to the stroller.
 - Do not exceed the infant carseat manufacturer's maximum weight limit when using an infant car seat with the stroller.
 - Do not use stroller with a child who weighs more than 40 lbs (18kg).
 - Do not use stroller with a child taller than 40 inches (101 cm).
 - Do not overload basket – Maximum weight in basket is 8 lbs (3.6kg).
 - Maximum weight in the canopy pouch is 0.5 lbs (0.25 kgs)
 - Do not overload the stroller, it may become unstable Max load is 48.5 lbs (22 kgs)
 - Overloading the basket may cause the stroller to become unstable.
 - Always make certain that the stroller is fully open and locked in the open position before use.
 - Do not hang or place items such as bags or parcel racks if on the stroller handle or frame (except for those approved by guzzie+Guss). They may cause the stroller to become unstable.
 - The stroller will become unstable if a parcel bag or parcel rack is being used when there is no provision for one
 - Do not allow children to climb on or play with the stroller.
 - Never use stroller on stairs or escalators
 - This stroller is intended for walking speed only. Do not use while jogging, skating, etc.
 - Always set the brake when stroller is not moving.
 - Only use accessories and replacement parts approved by guzzie+Guss
 - Read these instructions before using this product.
 - To ensure proper use, store this user guide in a convenient place so it can be consulted.
 - Failure to follow all warnings and instructions could result in serious injury or death.
- 2 • Do not use this stroller if there are any broken or missing parts.

ASSEMBLY

For your convenience, our stroller is ready to use right out of the box, no assembly required.

USING YOUR STROLLER

Opening

To open the stroller, first locate the frame lock on the left side of the stroller, and release the latch.

Then lift up on the handle allowing the frame to open. Test that the frame is properly locked open by pushing down on the handle.



Folding

To fold the stroller, first slide the button to the left, and while holding the position, squeeze the trigger and the frame will unlock and start to fold.



USING YOUR STROLLER

Seat recline

To adjust the angle of your seat, squeeze the clamp on the back of the seat and pull down to the desired position.



Footrest

To adjust the footrest position, pull the trigger release on each side of the footrest, then lower the footrest.

To raise the footrest just lift the footrest up, it will lock into place.



Ventilation

To add some ventilation, there are flaps on either side of the seat, just undo the Velcro and roll up the flap inward and tuck it behind the frame.



USING YOUR STROLLER

Canopy

The canopy has two zippered pleats to allow you to customize the sun protection as well as to add more airflow with the mesh sides.



To remove the canopy, you will need to use a tool (like a flathead screwdriver) to push the release tab, and then pull the canopy frame out of the ratchet.



Once the frame has been removed from the ratchet, you then need to unzip the canopy.



USING YOUR STROLLER

Harness

To use the 5-point harness, connect the shoulder belt with the waist belt, and then insert the buckle into the crotch receptacle, repeat on the other side.

To remove the straps, press the circular release button, and slide the waist straps out.



The shoulder harness is adjustable in height and can be changed by unthreading the shoulder strap from its current position and rethreading it through the shoulder belt positioning slot at the desired height.

The length of the shoulder straps can also be changed by sliding the buckle on each shoulder strap.

The waist belts are adjustable on either the right or left by using the adjustment buckles on the waist strap.



USING YOUR STROLLER

Parking brake



To set your parking brake, push down on the brake pedal.



To release the parking brake, push down on the inner portion of the brake pedal.

NOTE: Pull back on the stroller after you have applied the brake to ensure that the brake has fully engaged.

Footrest enclosure

Under the footrest there is a flap of material on either side, these will be able to be zippered onto the side of stroller seat to make the footrest enclosure.



NOTE: When using the stroller seat from birth to 4 months always use the footrest enclosure and have the seat fully reclined.



USING YOUR STROLLER

Car seat compatibility

The Oxygen stroller has the ability to carry an infant car seat (some models may not work, please contact us for an updated list of compatible seats).

Car seat security strap packed with the included travel bag.

First you need to attach both ends of the car seat safety strap to the 2 anchor points located under the seat.



Then you need to lift the footrest up to 90 degrees and using the footrest enclosure zippers. (as described on page 7)



Then place your car seat facing the handles, and resting on the footrest. It should fit snugly between each sides of the seat.

Position the car seat safety strap over the front of the infant car seat, and connect the buckles.
Note: make sure to feed the straps through your car seat's lap belt pathway (if yours has one).

Lastly, tighten the straps until the infant car seat is snugged in the stroller seat.


Warning: make sure when using this feature the child is always strapped into your infant car seats' 5-point harness.



USING YOUR STROLLER

Wheels

To remove the front wheel, push in the release button, and slide out the wheel.



To remove the rear wheels you will need a phillips screwdriver. Unscrew the locking screw on the underside of the frame and pull the wheel out.



Note: This only needs to be done for repair or maintenance purposes as you should remove the wheels to clean and lubricate them.


CARE & MAINTENANCE

- Check the rivets, brakes and accessories very carefully before using this stroller.
- Stop using this product if there is any damage or broken parts or pieces.
- Lubricate all moving parts and joints with a penetrating spray lubricant, from time to time.
- Remove front and rear wheels from housings and clean thoroughly once a month.
- Clean the stroller frame by wiping with moist cloth and dry thoroughly to prevent any rusting.
- Always wipe dry your stroller after using it in the rain or in winter climates, making sure road salt is removed from frame and joints. Allow the stroller to stand in an open, warm and ventilated place to dry.
- Do not leave your stroller outside in wet or hot/sunny weather, as the fabric could mildew or fade.
- Do not leave your stroller outside in cold weather as the cold could have adverse effects on the stroller.
- Only hand-wash the fabric by using mild detergent in warm water. Do not wash in machine. Hang in a ventilated place to dry. Do not tumble dry. Do not use bleach. Do not iron.
- It may be unsafe to use accessories other than those approved by the manufacturer or distributor.
- It may be unsafe to use replacement parts other than those supplied or approved by the manufacturer or distributor.

If you have any questions regarding the product please contact guzzie + Guss at 1-888-597-0992, or online at

Additional Care instructions:

- Hand wash in cold water
- No Bleach
- Drip Dry
- Do not machine dry
- Do not Iron



WARRANTY

Your guzzie+Guss item is warranted to be free from any manufacturing defects for 1 year from the date of purchase under normal use and in compliance with the operating instructions. This warranty cannot be extended and an extended warranty cannot be purchased. This warranty is not transferable and extends only to the original retail purchaser and is only valid when supplied with proof of purchase. PLEASE RETAIN PROOF OF PURCHASE FOR THIS LIMITED WARRANTY. The warranty is valid only in the original country of purchase (1 year on the frame and wheels, 6 months on the fabric).

This warranty is subject to the conditions set forth by country in which the items were purchased. Conditions may vary. guzzie+Guss will not ship replacement or repair parts out of the country of purchase. guzzie+Guss will provide replacement parts or conduct repairs as determined fitting by the company. guzzie+Guss reserves the right to exchange item with a replacement part. Some parts may be replaced with newer model parts as the items are improved over time. Please NOTE that all issues will NOT be covered by this warranty if it is deemed that your unit has been damaged because of misuse or neglect of regular maintenance.

Warranty is nullified if:

- The issue is caused by misuse or poor maintenance. Please refer to this instruction booklet for guidance on stroller use and maintenance.
- Damage is caused by improper installation of guzzie+Guss parts and/or accessories. Please refer to this instruction booklet for guidance on stroller assembly and use.
- Damage is corrosion, mold or rust caused by lack of maintenance or service.
- Damage is due to general wear and tear, which is the result of everyday use or negligence.
- Damage is caused by sun intensity, sweat, detergents, damp storage or frequent washings.
- Repairs or modifications are carried out by an unauthorized third party.
- Stroller is purchased from an unauthorized retailer. Approved retailers are listed on our website at www.guzzieandguss.com
- Stroller is second-hand.
- Stroller is damaged as a result of an accident, airline or freight damage. guzzie+Guss reserves the right to determine if warranty terms and conditions have been met. Please contact your local distributor if you have any questions regarding warranty.