

Hitch

Accessory Seat

Imported in North America by :
Peter John M. Distributions inc.
#114 - 6951 - 72nd street
Delta, BC, Canada V4G 0A2

info@guzzieandguss.com
1-888-597-0992

Please read this instruction manual carefully before using this product.
Be sure to save these instructions for future reference.

Thank you for purchasing the guzzie+Guss Hitch seat. Given all products out there, choosing the right product to fit your needs can be a challenge and we are honored that you have decided to go with guzzie+Guss. We are committed to producing quality products that offer clever solutions, and are easy to use, so that you can focus on having fun! Please do feel free to reach out to us with any questions, comments, or if you need assistance with your guzzie+Guss product.

IMPORTANT

It is important that you read and follow the instructions in this manual. Please ensure that all parts are properly attached and moving parts are in working order. Read all warnings and safety precautions before using.

Having read and followed all instructions in this manual, please keep it in a safe place to review if necessary. If you have a problem with the assembly of the Hitch or use, please contact guzzie+Guss at info@guzzieandguss.com. A member of our team will be very happy to help you. You will be asked to provide us the serial number and date of manufacture; this information can be found on the side of the seat mechanism.

What is included in the box:

- 1) Seat Post
- 2) Seat
- 2) Handle Frame
- 3) Instructions with 2 screws, bolt and locking nut

COMPONENTS

Seat Post



Seat



Handle Frame



! WARNINGS

Please note the following to ensure safe use of your stroller

READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF THE HITCH SEAT. KEEP INSTRUCTIONS FOR FUTURE USE

- NEVER leave your child unattended, even for a short time
- The intended use is for 1 child at a time, approximate minimum age of 2 years old, maximum weight of 20 kgs (44 lbs)
- Always keep your hands on the stroller when the child is using the Hitch or the seat. NEVER LEAVE THE CHILD UNATTENDED.
- Before each use, check that the Hitch connectors are secure and tighten if necessary.
- Do not use the Hitch Seat, if there are any broken or missing parts. Test the seat and handle every time prior to using to make sure they are secured.
- Always use the attached seat belt when using this product.
- Never let children play with the Hitch, it is not a toy.
- The use of any accessories with the Hitch that have not been approved by guzzie+Guss is not recommended.

ASSEMBLY





Insert the handle frame into the square receptacle in the front of the seat. (pic1)

Line up the holes in the handle frame with the 2 holes on the underside of the seat, secure the handle by screwing the 2 screws through the holes. (pic2)

Note: Please check that the handle is attached to the seat securely by testing the handle.

Align the seat on the top of the seat post, slide the bolt through the hole and secure using the locking nut. (pic3 and pic4)


NOTE: Make sure the bolt is secure before using



ASSEMBLY

To attach the seat to the Hitch, line up the 2 metal brackets on the bottom of the seat assembly with the 2 slots on the board of your Hitch.

Insert the brackets into the slots and rest the platform on the Hitch board.



Unlock the clamp by releasing the locking tab, and extend the latch under the edge of the hitch board. Make sure to line up the lip on the inside of the hitch


Lift the latch upwards, and flip the locking tab down and over the tab. Verify that the seat is now locked into place.



USING YOUR SEAT

To adjust the seat height for your child push the silver button in and raise or lower the seat to the desired position.

WARNING: Make sure the pin is properly seated in the appropriate hole.



CARE & MAINTENANCE

- Regularly check the Seat for any damage or for missing components. Use only guzzie+Guss approved replacement parts available through authorized service centers.
- To clean, wipe with a soft damp cloth and mild soap or cleaning solution. Do not use harsh abrasives.
- Always dry metal parts to avoid the formation of rust.
- Continued and extended exposure to sunlight and the elements can change the color of many materials. To avoid fading, always cover and store in a shaded area.
- Always store in a well ventilated area.

WARRANTY

Your guzzie+Guss item is warranted to be free from any manufacturing defects for 1 year from the date of purchase under normal use and in compliance with the operating instructions. This warranty cannot be extended and an extended warranty cannot be purchased. This warranty is not transferable and extends only to the original retail purchaser and is only valid when supplied with proof of purchase. PLEASE RETAIN PROOF OF PURCHASE FOR THIS LIMITED WARRANTY. The warranty is valid only in the original country of purchase (1 year).

This warranty is subject to the conditions set forth by country in which the items were purchased. Conditions may vary. guzzie+Guss will not ship replacement or repair parts out of the country of purchase. guzzie+Guss will provide replacement parts or conduct repairs as determined fitting by the company. guzzie+Guss reserves the right to exchange item with a replacement part. Some parts may be replaced with newer model parts as the items are improved over time. Please NOTE that all issues will NOT be covered by this warranty if it is deemed that your unit has been damaged because of misuse or neglect of regular maintenance.

Warranty is nullified if:

- The issue is caused by misuse or poor maintenance. Please refer to this instruction booklet for guidance on use and maintenance.
 - Damage is caused by improper installation of guzzie+Guss parts and/or accessories. Please refer to this instruction booklet for guidance on assembly and use.
 - Damage is corrosion, mold or rust caused by lack of maintenance or service.
 - Damage is due to general wear and tear, which is the result of everyday use or negligence.
 - Damage is caused by sun intensity, sweat, detergents, damp storage or frequent washings.
 - Repairs or modifications are carried out by an unauthorized third party.
 - Seat is purchased from an unauthorized retailer. Approved retailers are listed on our website at www.guzzieandguss.com
 - Seat is second-hand.
 - Seat is damaged as a result of an accident, airline or freight damage.
- guzzie+Guss reserves the right to determine if warranty terms and conditions have been met. Please contact your local distributor if you have any questions regarding warranty.